

INSTALLATION INSTRUCTIONS FOR SHU HANGER

- 1) LOCATE EACH ISOLATOR INTO POSITION BASED ON SUBMITTAL DRAWING USING COLOR CODED SPRINGS AS IDENTIFICATION.
- 2) POSITION EQUIPMENT SUPPORT ON THREADED ROD.
- 3) ATTACH ISOLATOR BELOW EQUIPMENT SUPPORT AS SHOWN IN SKETCH.
- 4) ADJUST EQUIPMENT LEVEL BY THE LEVEL ADJUSTMENT NUT ON THE BOTTOM OF THE ISOLATOR AS SHOWN IN SKETCH.
- 5) CHECK FOR PROPER ALIGNMENT.

